

One Little Remove V3 – Cheat Sheet

Function	Mode	Button	Confirmation
Record	1 – 1x dial	1x button 1	LED low continual flash when active
Focus	1 – 1x dial	1x button 2	
Iris	1 – 1x dial	1x button 3	
WB	1 – 1x dial	1x button 4	
ISO	1 – 1x dial	2x button 2	
Shutter angle	1 – 1x dial	2x button 3	
Audio Levels	1 – 1x dial	2x button 4	
Auto focus	1 – 1x dial	Hold button 1	
Auto exposure	1 – 1x dial	Hold button 2	
Set focus stop 1	1 – 1x dial or 2x dial	Hold button 3	LED short strobe
Set focus stop 2	1 – 1x dial or 2x dial	Hold button 4	LED short strobe
Use focus stop 1	2 – 2x dial	1x button 3	
Use focus stop 2	2 – 2x dial	1x button 4	
Zoom in	3 – 3x dial	Hold button 4	
Zoom out	3 – 3x dial	Hold button 3	
Pick zoom speed	3 – 3x dial	1x button 2, then 1x button 1 (slowest), 2, 3 or 4 (fastest)	LED flash 1-4 times to confirm which speed
Pick focus speed	1 – 1x dial	1x button 2, then 1x button 1 (slowest), 2, 3 or 4 (fastest)	LED flash 1-4 times to confirm which speed
Pick focus stop speed	2 – 2x dial	1x button 2, then 1x button 1 (slowest), 2, 3 or 4 (fastest)	LED flash 1-4 times to confirm which speed
Restart remote		Dial + button 3	LED 5 flashes at restart
Reprogram remote	Use only when installing new firmware	Dial + button 3 + button 4	LED 5 flashes at restart
RF Master Mode toggle on/off		Dial + button 2	LED solid – except when recording
RF Slave Mode toggle on/off		Dial + button 1	LED pulses continually

Mini cheat sheet

Record	1 – 1x dial	1x button 1
Focus	1 – 1x dial	1x button 2
Iris	1 – 1x dial	1x button 3
WB	1 – 1x dial	1x button 4
ISO	1 – 1x dial	2x button 2
Shutter angle	1 – 1x dial	2x button 3
Audio Levels	1 – 1x dial	2x button 4
Auto focus	1 – 1x dial	Hold button 1
Auto exposure	1 – 1x dial	Hold button 2
Set focus stop 1	1 – 1x dial or 2x dial	Hold button 3
Set focus stop 2	1 – 1x dial or 2x dial	Hold button 4
Use focus stop 1	2 – 2x dial	1x button 3
Use focus stop 2	2 – 2x dial	1x button 4
Zoom in	3 – 3x dial	Hold button 4
Zoom out	3 – 3x dial	Hold button 3
Pick zoom speed	3 – 3x dial	1x button 2, then 1x button 1, 2, 3 or 4
Pick focus speed	1 – 1x dial	1x button 2, then 1x button 1, 2, 3 or 4
Pick focus stop speed	2 – 2x dial	1x button 2, then 1x button 1, 2, 3 or 4